

What are the hazards and how might they harm?



Environmental pollution from spillages



Back and muscle strain from manual handling

What PPE should the individual wear?



Pedestrian line markers

Safety Task Card STCBG 17

Safe System of Work

1. You must wear reinforced toe cap safety shoes.
2. Follow the safety precautions in the COSHH Product Assessments for the paint and any cleaning products being used. This includes wearing PPE such as protective eyewear and gloves.
3. Implement safe manual handling practices when lifting paint and water containers to fill line marker.
4. When preparing paint from a concentrate, water should always be added first, then the paint.
5. Ensure the controls on STCGE 32 are implemented when charging batteries.
6. Do not open any pipe joints while the pump is on when using pressurized line markers.
7. Do not pour left over paint mix onto grass surfaces, down drains or into water courses.
8. When rinsing equipment do this over a suitable container to catch wastewater and ensure that it cannot enter water courses.

If you have any concerns, stop and speak with your line manager before proceeding

