


AUTOMATIC DISHWASHER DETERGENT - Topmatic Crystal GB Special

READ BEFORE STARTING PROCEDURE



Use your cleaning tools –
Blue paper towels

Please reference the relevant
Safety Data Sheets, risk
assessment and safe system
at work documents.



WS.TC.006.01

1

Always wear correct PPE



2

Undo cap on empty
bottle and carefully
remove feed pipe



3

Remove empty bottle
and replace with new
bottle



4

Undo cap on new
bottle and carefully
place in feed pipe



5

Tighten cap and
wipe away any
chemical drips



6

Place new cap on old
bottle and dispose of
or recycle



Helpline: 02920 855540

