

# DISHWASHER DESCALING – Lime-A-Way Extra

## READ BEFORE STARTING PROCEDURE



Use your cleaning tools –  
Blue paper towels

Please reference the relevant  
Safety Data Sheets, risk  
assessment and safe system  
at work documents.



WS.TC.054.01

1

Always wear correct PPE



2

Turn off power to  
dishmachine, drain  
fully and remove the  
detergent feed pipe




3

Pour Lime-A-Way  
Extra in to the  
main tank



4

Run through  
several cycles



5

Re-attach  
detergent feed pipe  
and run machine  
once before filling  
with items to clean



Helpline: 02920 855540

**ECOLAB**<sup>®</sup>